

# Cleaning instructions

## for ONEFLOR-EUROPE LVT with ECOPROTEC™ Technology

### General advice

- Clean the floor covering regularly, as this is more cost-effective and hygienic than infrequent heavy-duty cleaning.
- Always follow the dosage instructions carefully.
- Wipe up any grease and spilt oil immediately, as these substances may damage the surface.
- Avoid using solvents on resilient floors, as they can cause damage.
- Note that black rubber wheels and rubber feet can discolour the floor covering.
- Ensure that all chair and table legs have high-quality feet (felt feet are not recommended in commercial interiors; hard plastic is preferred).
- Remember that light-coloured surfaces require more frequent cleaning.

### Preventive care



#### Entrance matting

Approximately 80% of the surface soiling that requires cleaning originates from outside. Up to 90% of this soiling can be prevented with an effective, properly sized entrance mat. Minimizing the amount of dirt entering the premises reduces overall maintenance requirements.

### Daily and regular cleaning



#### Dry mopping

Remove dust and dirt with dry mop.

or



#### Vacuum cleaning

To remove dust and loose dirt. Recommended for large areas and initial site cleaning.



#### Damp mopping

Use a mop dampened with water or detergent solution. It is essential that water does not stay on the floor or leave a film. The floor should be virtually dry after 15-20 seconds.

or



#### Combined machine with brush

Industrial machine-cleaning (large areas). Use diluted neutral detergent. Adjustable speed 300-500rpm. Use a nylon brush instead of a white/beige pad !



#### Manual brush

Brush (with medium brushes).

or



#### Rotowash with brushes

Spray diluted detergent and clean with water or water+detergent.



#### Spot and stain removal

Treat stains immediately. Hand spot using a white/red nylon pad with neutral detergent (solvents should not be used). Work from the outside of the mark towards its centre. Rinse and wipe afterwards with clean water.

### Periodical cleaning

#### Light cleaning



#### Spray Cleaning

Mix water and neutral detergent in the container tank. Suitable speed 300-500rpm. A red pad is recommended.

#### Heavy cleaning



#### Rotowash

Clean with the cylindrical scrubbing machine (spray detergent diluted with water through the machine).

#### If needed



#### Dry buffing

When necessary, dry buff to recover gloss. Use a white-beige pad. Operate at a suitable speed of 500-1000 rpm.

### ECOPROTEC™ Technology

LVT surface coating technology. Proven to remove 99.9% of bacteria safely. Offers superior scratch and stain resistance (2x stronger).

#### SAFE

Formulation featuring the ECOPROTEC™ active anti-bacterial ingredient. Registered by the US EPA (US Environmental Protection Agency). Formulated without using nano-silver.

#### STRONG

The LVT surface coating technology offers twice the scratch and stain resistance. It has been proven to safely remove 99.9% of bacteria.

### Initial site cleaning

Always protect the floor with thick paper or hard board during the construction period.

After the installation, always clean the new floor: vacuum, sweep or damp mop the area to remove building dust and loose dirt.

A combined scrubber/dryer with cylindrical brushes is very effective to clean large areas.

Use detergent with a low pH.